AIRPORT DIAGRAM
25107

GEORGE BUSH INTCNTL/HOUSTON (IAH)
HOUSTON, TEXAS

D-ATIS
124.05
HOUSTON TOWER
120.725 290.2 (RWY 08L-26R)
125.35 290.2 (RWY 08R-26L)
127.3 288.25
(RWYS 15L-33R, 15R-33L)
135.15 290.2 (RWY 09-27)
GND CON
118.575 (RWYS 08L-26R, 09-27)
121.7 (RWYS 15L-33R, 15R-33L)
CLNC DEL
128.1
GND METERING
119.95
CPDLC
PDC

D

FIELD ELEV 96

ELEV 91
088.1°
9000 X 150
268.2°
ELEV 94
8L
26R
FIRE STATION
NE BRIDGE
FH BRIDGE
ELEV 94
LAHSO
ILS HOLD
ELEV 95
8R
088.1°
9402 X 150
268.2°
LAHSO
ELEV 92
26L
EAST CARGO
ELEV 95
TERM A
TERM B
TERM C
TERM D
EAST BRIDGE
TWR 424
HANGARS
ILS HOLD
CENTRAL CARGO
RA BRIDGE
RB BRIDGE
SC BRIDGE
SF BRIDGE
FIRE STATION
150.2°
10000 X 150
12001 X 150
330.2°
088.2°
10000 X 150
268.2°
ELEV 90
27
ELEV 84
FIRE STATION
HANGAR
FBO RAMP
FBO RAMP
ELEV 87
33L
ELEV 85
33R

VAR 1.8° E
JANUARY 2025
ANNUAL RATE OF CHANGE
0.1° W

Runway Status Lights in operation.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

HIRL Rwys 15L-33R, 15R-33L, 8R-26L, 9-27 and 8L-26R
TDZ/CL Rwys 15R, 33L, 8R, 26L, 27, 8L and 26R

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

RWY 08L-26R
PCR 1100 R/A/W/T
S-75, D-210, 2D-409, 2D/2D2-873
RWY 08R-26L
PCR 1090 R/A/W/T
S-75, D-210, 2D-498, 2D/2D2-873
RWY 09-27
PCR 690 R/A/W/T
D-210, 2D-560
RWY 15L-33R
PCR 870 R/B/W/T
S-100, D-200, 2D-400, 2D/2D2-800
RWY 15R-33L
PCR 980 R/A/W/T
S-75, D-200, 2D-400, 2D/2D2-873

30°00′N
29°59′N
29°58′N
95°23′W
95°22′W
95°21′W
95°20′W
95°19′W
95°18′W

AL-5461 (FAA)

AIRPORT DIAGRAM
25107
GEORGE BUSH INTCNTL/HOUSTON (IAH)
HOUSTON, TEXAS